

RSL20H

PSI	TORQUE OUT FT LBS	PSI	TORQUE OUT FT LBS
1000	1957	6000	11338
1200	2332	6200	11713
1400	2708	6400	12089
1600	3083	6600	12464
1800	3458	6800	12839
2000	3833	7000	13214
2200	4209	7200	13589
2400	4584	7400	13965
2600	4959	7600	14340
2800	5334	7800	14715
3000	5710	8000	15090
3200	6085	8200	15466
3400	6460	8400	15841
3600	6835	8600	16216
3800	7210	8800	16591
4000	7586	9000	16967
4200	7961	9200	17342
4400	8336	9400	17717
4600	8711	9600	18092
4800	9087	9800	18467
5000	9462	10000	18843
5200	9837		
5400	10212		
5600	10588		
5800	10963		