

RSL4

PSI	TORQUE OUT		PSI	TORQUE OUT	
	LBS-FT	Nm		LBS-FT	Nm
1000	290	393	6000	1840	2495
1200	352	477	6200	1902	2579
1400	414	561	6400	1964	2663
1600	476	645	6600	2026	2747
1800	538	729	6800	2088	2831
2000	600	813	7000	2150	2915
2200	662	898	7200	2212	2999
2400	724	892	7400	2274	3083
2600	786	1066	7600	2336	3167
2800	848	1150	7800	2398	3251
3000	910	1234	8000	2460	3335
3200	972	1318	8200	2522	3419
3400	1034	1402	8400	2584	3503
3600	1096	1486	8600	2646	3587
3800	1158	1570	8800	2708	3672
4000	1220	1654	9000	2770	3756
4200	1282	1738	9200	2832	3840
4400	1344	1822	9400	2894	3924
4600	1406	1906	9600	2956	4008
4800	1468	1990	9800	3018	4092
5000	1530	2074	10000	3080	4176
5200	1592	2158			
5400	1654	2243			
5600	1716	2327			
5800	1778	2411			